


Boraam Industries

ASSEMBLY INSTRUCTIONS

SKU: 60524,60529,60924,60929,60824,60829 BLOOMINGTON SWIVEL STOOL





Weight Capacity

Version 1 / Updated as of 11-17-23



Have questions about assembling your item?



Items or parts damaged?



Missing a part?

We're here to help! (Monday-Friday from 9am-5pm CST)



847-949-6300 877-267-2261



customerservice@ boraamindustries.com




www.boraamindustries.com


Page 1 of 09

Assembly And Care


- · All tools required for assembly are included unless noted.
- · Prior to assembly, check for missing or damaged parts.
- Do not dispose of packaging materials until assembly is completed.
- Assemble item on a soft, clean surface to prevent damage to the item.




Assembly Overview




PARTS




HARDWARE






DO NOT TIGHTEN BOLT COMPLETELY.

02




Hardware	Count
Α	4
В	4
D	4
G	1

TIGHTEN BOLT COMPLETELY.




TIGHTEN BOLT COMPLETELY.



Hardware	Count
Α	4
В	4
С	4
G	1

TIGHTEN BOLT COMPLETELY.



BE SURE TO CHECK ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.