




Boraam Industries

ASSEMBLY INSTRUCTIONS

SKU: 75032

SONOMA TV STAND



Have questions about assembling your item?



Items or parts damaged?



Missing a part?

We're here to help! (Monday-Friday from 9am-5pm CST)




847-949-6300
877-267-2261




customerservice@
boraamindustries.com




www.boraamindustries.com




Wood Nut
4 PCS




M6*30
4 PCS



M6*40
4 PCS




M6*45
4 PCS




1 PC


1




2






3



4






01






DO NOT TIGHTEN BOLT COMPLETELY.

02






DO NOT TIGHTEN BOLT COMPLETELY.


03



TIGHTEN BOLT COMPLETELY.

04





BE SURE TO CHECK ALL BOLTS ARE SECURELY
TIGHTENED PRIOR USING THIS TV STAND.