


### **Boraam Industries**

**ASSEMBLY INSTRUCTIONS** 

SKU: 42824,42829,42924,42929,42524,42529,42424,42429 BRISTOL SW IVEL STOOL





Weight Capacity



Locate the
HARDWARE PACK
which is attached to
the shipping carton
with red tape.

02/2024



Have questions about assembling your item?



Items or parts damaged?



Missing a part?

We're here to help! (Monday-Friday from 9am-5pm CST)



847-949-6300 877-267-2261



customerservice@ boraamindustries.com



www.boraamindustries.com


Page 1 of 09

## **Assembly And Care**


- All tools required for assembly are included unless noted.
- Prior to assembly, check for missing or damaged parts.
- Do not dispose of packing materials until assembly is completed.
- Assemble item on a soft, clean surface to prevent damage to the item.




# **Assembly Overview**




#### **PARTS**




### **HARDWARE**







Please make sure that the protective metal kick plate from Footrest (Part #3) is facing upwards. Remove the white Tape from the protective metal kick plate before using.




Page 6 of 09



TIGHTEN BOLT COMPLETELY.



Page 8 of 09



BE SURE TO CHECK ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.