


## **Boraam Industries**

**ASSEMBLY INSTRUCTIONS** 

#### SKU: 98520,98523 SONOMA KITCHEN CART



01/2024



Have questions about assembling your item?



Items or parts damaged?



Missing a part?

#### We're here to help! (Monday-Friday from 9am-5pm CST)



847-949-6300 877-267-2261



customerservice@ boraamindustries.com



www.boraamindustries.com


Page 1 of 13

## **Assembly And Care**


- All tools required for assembly are included unless noted.
- · Prior to assembly, check for missing or damaged parts.
- Do not dispose of packing materials until assembly is completed.
- Assemble item on a soft, clean surface to prevent damage to the item.



## **Assembly Overview**





### **PARTS**




## **HARDWARE**

(A) (x16)	B (x8)	© (x2)	(x2)
Wood Nut	Flat Washer	Caster	Caster With Lock






# 02





DO NOT TIGHTEN BOLT COMPLETELY.


- Make sure the insert nuts are in the correct position before assembling.
  You will need a screwdriver to turn the nuts into the correct position as shown below.




This is to prepare for step 04













BE SURE TO CHECK ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.