








70100 / 70500

ASSEMBLY INSTRUCTIONS



NO.	DESCRIPTION		QTY
A.	TABLE TOP		1 PC
B	TABLE LEG		4 PCS
C	FLAT WASHER		8 PCS
D	HEX NUT		8 PCS
E	SPRING WASHER		8 PCS
F	SPANNER		1 PC

1. TURN THE UNDERSIDE OF THE FARM HOUSE TABLE OVER AND PLACE IT ON A PIECE OF CLOTH ON THE FLOOR.
2. FIX THE TURNED LEG TO THE CORNER OF THE APRON WITH FLAT WASHER, SPRING WASHER AND HEX NUT USING THE SPANNER PROVIDED TO TIGHTEN.
3. REPEAT THE SAME OF THE OTHER THREE LEG.
4. TURN THE ASSEMBLE TABLE OVER CAREFULLY.

