




Boraam Industries

ASSEMBLY INSTRUCTIONS

SKU: 54124,54224,55124,54129,54229,55129,56124,56129
BALI SWIVEL STOOL



Weight Capacity



Locate the
HARDWARE PACK
which is attached to
the shipping carton
with red tape.

10/2024



Have questions about
assembling your item?



Items or parts damaged?



Missing a part?

We're here to help! (Monday-Friday from 9am-5pm CST)



847-949-6300
877-267-2261



customerservice@
boraamindustries.com







www.boraamindustries.com

Assembly And Care


- All tools required for assembly are included unless noted.
- Prior to assembly, check for missing or damaged parts.
- Do not dispose of packing materials until assembly is completed.
- Assemble item on a soft, clean surface to prevent damage to the item.







Locate the
HARDWARE PACK
which is attached to the
shipping carton with red
tape.








Assembly Overview



PARTS


<p>① (x2)</p> <p>Leg:</p> 	<p>② (x2)</p> <p>Stretcher:</p> 
<p>③ (x1)</p> <p>Apron with swivel plate:</p> 	<p>④ (x1)</p> <p>Seat:</p> 

HARDWARE


<p>Ⓐ (x8)</p>  <p>Spring Washer M6*10</p>	<p>Ⓑ (x8)</p>  <p>Flat Washer M6*13</p>	<p>Ⓒ (x4)</p>  <p>Bolt M6*25</p>	<p>Ⓓ (x4)</p>  <p>Bolt M6*70</p>	<p>Ⓔ (x1)</p>  <p>Allen Key M4*110</p>
--	--	---	---	---

01

- Locate both leg assemblies (Part 1) and stretchers (Part 2).
 - Starting with one stretcher, match the letter on the ends of the stretcher to the letter on the threaded holes on the legs.
 - Repeat above step for the remaining stretcher.
 - With both stretchers inserted in BOTH leg assemblies, tighten both stretchers **SIMULTANEOUSLY** by turning them towards each other until completely tightened in both legs.
 - When both stretchers are installed, check for tightness before proceeding to the next assembly step.
- !! Hand tighten stretchers only, do not use any tools !!**




02



Hardware	Count
A	4
B	4
D	4
E	1

TIGHTEN BOLT COMPLETELY


03




TIGHTEN BOLT COMPLETELY

04


Finish tightening
Spindles (2) to Legs (1)



05



NOTE: USE THE ADJUSTABLE GLIDES TO ADJUST ALL 4 LEGS EVENLY ON THE FLOOR.



Weight Capacity

BE SURE TO CHECK ALL BOLTS ARE SECURELY TIGHTENED PRIOR TO USE.

847-949-6300 | 877-267-2261 | customerservice@boraamindustries.com